1	Before driving	1-4.	Opening and closing the windows and moon roof	89
			Power windows	89
1-1.	Key information28		Moon roof	9 <sup>.</sup>
	Keys 28	1-5.	Refueling	94
1-2.	Opening, closing and locking the doors and trunk		Opening the fuel tank cap	94
	Smart access system with push-button start	1-6.	Theft deterrent system	97 99
1-3.	Adjustable components	1-7.	Safety information	102
	(seats, mirrors,		Correct driving posture	102
	steering wheel)59		SRS airbags	
	Front seats		Front passenger occupant classification system Child restraint systems Installing child restraints	123
	Power rear seat (4-seat models)	2	When driving	
	Rear seat position memory	2-1.	Driving procedures  Driving the vehicle  Engine (ignition) switch  Automatic Transmission  Turn signal lever  Parking brake	138 146 150 155
			Brake Hold	159

	Gauges and meters 161	3	Interior features
	Indicators and warning lights 164		
	Multi-information display 168	3-1.	Using the touch screen 240
2-3.	Operating the lights and		Touch screen (without navigation system)240
	windshield wipers172		Setting the touch screen 243
	Headlight switch172		
	Fog light switch 175	3-2	. Using the air conditioning
	Windshield wipers and		system and defogger 248
	washer 176		Front air conditioning system
	Headlight cleaner switch 181		(without touch screen) 248
2-4.	Using other driving systems 182		Front air conditioning system (touch screen without rear
	Cruise control 182		air conditioning system) 257
	Dynamic radar cruise control		Front air conditioning system (touch screen with rear air conditioning system) 266
	Intuitive parking assist-sensor		Rear air conditioning system 276
	Electronically modulated air suspension		Rear window and outside rear view mirror defoggers
	Rear view monitor system 206		Windshield wiper de-icer 284
	Driving assist systems	3-3	. Using the audio system 286
	Pre-Collision System		Audio system
			(without touch screen)286
			Using the radio 288
2-5.	Driving information227		Using the CD player 292
	Cargo and luggage 227		Playing back MP3 and WMA discs298
	Vehicle load limits 230		Optimal use of the audio
	Winter driving tips 232		system
	Trailer towing236		Using the AUX adapter 306
	Dinghy towing 237		

3 Interior features

2-2. Instrument cluster...... 161

	Using the steering wheel audio switches	307		Playing the HDD audio (vehicles with navigation	
	Audio system			system)	382
	(touch screen without			Playing a DVD video/audio	383
	navigation system)3	309		Playing a video CD	396
	Using the radio	312		DVD player and DVD video	
	Using the CD player	317		disc information	400
	Playing MP3 and			Using the video mode	409
	WMA discs	325		Changing other setting	411
	Using the DVD player3	332			
	Playing DVD video/audio 3	335	3-5.	Using the hands-free system	
	Playing a video CD 3	348		(for cellular phone)	. 413
	DVD player and DVD video disc information	352		Hands-free system (for cellular phone)	<i>4</i> 13
	Optimal use of the			Using the Bluetooth® phone	
	audio/video system 3	356		Setting the hands-free system	
	Using the AUX adapter 3			(for cellular phone)	
	Using the rear seat audio			(	
	controls	361	3-6.	Using the interior lights	457
	Using the steering wheel			Interior lights list	
	audio switches3	365		• Interior lights	
				• Personal lights	
3-4.	Using the rear seat				
	entertainment system	367	3-7.	Using the storage features	460
	Rear seat entertainment			List of storage features	460
	system features	367		• Glove box	
	Using the radio3	376		Coin holder	
	Using the front DVD player 3	377		• Door pockets	
	Using the rear DVD player 3	378		Cup holders     Console box	
	Playing an audio			• Cool box	
	CD/CD text	380		Auxiliary boxes	474
	Playing WMA				
	(front DVD player only)/	381			
	IMP.D GISCS	וסכ.			

Sun visors 476	4 1	Maintenance and care
Vanity mirror477		
Clock478	4-1.	Maintenance and care 536
Outside temperature display480		Cleaning and protecting the vehicle exterior 536
Ashtrays481		Cleaning and protecting
Cigarette lighter482		the vehicle interior539
Power outlet484		
Heated steering wheel 487	4-2.	Maintenance 542
Climate control seats/		$Main tenance\ requirements\ 542$
seat heaters 489		General maintenance544
Armrest (5-seat models) 493		Emission inspection and
Rear seat relaxation system (4-seat models)494		maintenance (I/M) programs547
Retractable table (4-seat models)496	4-3.	Do-it-yourself
Rear sunshade 498		maintenance548
Rear door sunshades 501		Do-it-yourself service
Trunk storage extension 504		precautions 548
Coat hooks 506		Hood 551
Floor mat 507		Positioning a floor jack 552
Trunk features 508		Engine compartment 554
Garage door opener511		Tires 570
Compass 517		Tire inflation pressure 578
Lexus Link System 521		Wheels 582
•		Air conditioning filter 584
		Electronic key battery587
		Checking and replacing
		(

3-8. Other interior features ........... 476

4	Maintenance and	care
---	-----------------	------

	Cleaning and protecting the vehicle exterior	536
	Cleaning and protecting the vehicle interior	539
<b>1-2</b> .	Maintenance	542
	Maintenance requirements	542
	General maintenance	544
	Emission inspection and maintenance (I/M)	
	programs	547
	5 1/	
1-3.	Do-it-yourself	T 40
	maintenance	548
	Do-it-yourself service precautions	548
	Hood	гг4
		. ၁၁۱
	Positioning a floor jack	
	Positioning a floor jack Engine compartment	552
	• ,	552 554
	Engine compartment	552 554 570
	Engine compartment	552 554 570 578
	Engine compartment  Tires  Tire inflation pressure	552 554 570 578 582
	Engine compartment  Tires  Tire inflation pressure  Wheels	552 554 570 578 582 584
	Engine compartment  Tires  Tire inflation pressure  Wheels  Air conditioning filter	552 554 570 578 582 584 587
	Engine compartment  Tires  Tire inflation pressure  Wheels  Air conditioning filter  Electronic key battery  Checking and replacing	552 554 570 578 582 584 587

5	When trouble arises	6 Vehicles	pecifications	
5-1.		•	ations	668
	If your vehicle needs to be towed		ance data   level, etc.)	668
	If you think something	, ,	mation	
	is wrong		mation	
	Fuel pump shut off system 627			
	Event data recorder 628	6-2. Customi	zation	692
		Customi	zable features	692
5-2.	Steps to take in an			
	emergency630	6-3. Initializa	tion	696
	If a warning light turns on or a warning buzzer sounds	ltems to i	nitialize	696
	If a warning message is displayed639	7 For owne	ers	
	If you have a flat tire		g safety defects owners	698
	If the shift lever cannot be shifted from "P"	Seat belt	instructions adian owners	
	If the parking brake cannot be released	(in Fren	ch)	699
	If you lose your keys 655	Index		
	If the electronic key does not operate properly	index		
	If the vehicle battery is discharged	Abbreviation	ist	702
	If your vehicle overheats 663	Alphabetical in	ndex	704
	If the vehicle becomes stuck 666	•		
		What to do if		714